

Tensioning the Twin Honeycomb Skylight Manual Blind

You need to tension the twin honeycomb manual skylight blind or this will happen



- Untighten the screws that are side fixing the blind into the walls
- Pack out the space between the rails and the walls (pushing the side rails inwards)
- Then increase the tension on each side of the blind following this [video](#)

